

# BIG BIKE PARTS®

## INSTALLATION INSTRUCTIONS

Copyright © 2005 by Big Bike Parts, Inc.  
No part of this instruction sheet may be  
reproduced without the written permission  
of Big Bike Parts, Inc.

PART NO. 53-715

SADDLEBAG STAYS

VT600 C/CD 02-04, C/CD 99-01, CD2 99-00

TOOLS NEEDED: 12MM SOCKET  
5MM ALLEN WRENCH

**NOTE: IT IS RECOMMENDED TO USE LOC-TITE ON ALL BOLTS.**

1. USING 12MM SOCKET AND 5MM ALLEN WRENCH, REMOVE THE BOLT AT THE FRONT OF FENDER STRUT.
2. USING 12MM SOCKET AND 5MM ALLEN WRENCH, REMOVE THE BOLT AT REAR OF FENDER STRUT.
3. USING M8 X 1.25 X 80MM LONG BOLT PROVIDED AT FRONT OF FENDER STRUT AND AT REAR OF FENDER STRUT, INSTALL THE SADDLEBAG STAY.
4. REPEAT STEPS 1 THROUGH 3 FOR OTHER SIDE.