BIG BIKE PARTS

Copyright© 2002 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

INSTALLATION INSTRUCTIONS

Rear Caliper Cover Part No. 55-121 Fits Honda VTX 1800

TOOLS NEEDED: 14MM SOCKET WRENCH 2.5MM ALLEN WRENCH

INSTALLATION:

1. USING 14MM SOCKET WRENCH REMOVE THE BOLT ON THE FAR RIGHT SIDE OF THE CALIPER. THE BOLT WILL PULL OUT ONCE UNSCREWED.

- 2. STICK THE FOAM TAPE ONTO THE FACE OF THE CALIPER.
- 3. POSITION THE REAR CALIPER COVER IN PLACE AND PUT THE BOLT BACK INTO CALIPER THROUGH THE HOLE IN THE CALIPER COVER.
- 4. PLACE THE "J" HOOK ON THE HOSE ON THE LEFT SIDE OF CALIPER AND SCREW IT DOWN WITH THE M3 X .40 X 8MM LONG SCREW PROVIDED.