BIG BIKE PARTS INSTALLATION INSTRUCTIONS

Copyright 2006 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 71-123

SWING ARM COVERS KAWASAKI VN2000

TOOLS NEEDED: 10MM SOCKET WRENCH

- 1. WITH A 10MM SOCKET WRENCH, REMOVE BOTH HEX HEAD CAP SCREWS FROM THE LEFT SIDE PASSENGER FOOT PEG BRACKET. DETACHING THE FOOT PEG ASSEMBLY FROM THE BIKE.
- 2. CLEAN THE LEFT SIDE SWING ARM COVER WITH A MILD SOLVENT, SUCH AS ACETONE, APPLIED WITH A CLEAN, LINT-FREE RAG WILL PREPARE THE SURFACE TO BE COVERED.
- 3. ONCE THE ADHESIVE CLEANER HAS DRIED. PEEL THE PLASTIC FILM OFF THE BACK OF THE TAPE MAKING SURE THAT THE HOLES IN THE COVER ARE ALIGNED WITH THE HOLES IN THE SWING ARM FOR THE PEG SCREWS. WHEN THEY ARE ALIGNED, PRESS THE COVER ONTO THE SWING ARM FIRMLY TO ENSURE GOOD CONTACT BETWEEN THE TAPE AND THE SWING ARM.
- 4. ATTACH THE LEFT SIDE PEG ASSEMBLY IN REVERSE ORDER OF REMOVAL. PUTTING ONE RUBBER WASHER OVER EACH SCREW BETWEEN THE PEG BRACKET AND THE SWING ARM COVER, THEN TIGHTEN DOWN WITH A 10MM SOCKET WRENCH.
- 5. WITH A 10MM SOCKET WRENCH, REMOVE BOTH HEX HEAD CAP SCREWS FROM THE RIGHT SIDE PASSENGER FOOT PEG BRACKET. DETACHING THE FOOT PEG ASSEMBLY AND HEEL GUARD.
- 6. REPEAT STEPS #2 & 3 FOR THE RIGHT SIDE SWING ARM COVER.
- 7. ATTACH THE RIGHT SIDE PEG ASSEMBLY AND HEEL GUARD IN REVERSE ORDER OF REMOVAL PUTTING ONE RUBBER WASHER OVER EACH SCREW BETWEEN THE HEEL GUARD AND THE SWING ARM COVER AND TIGHTEN DOWN WITH A 10MM SOCKET WRENCH.