

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2003 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

Saddlebag Stays
Part No. 82-209

Fits Suzuki
VL800 Volusia

TOOLS NEEDED:

6MM ALLEN WRENCH
5MM ALLEN WRENCH

INSTALLATION:

1. REMOVE THE TWO FENDER STRUT SCREWS.
2. INSTALL THE SADDLEBAG STAY USING THE NEW LONGER SCREWS PROVIDED.
3. REPEAT STEPS 1 & 2 FOR THE OTHER SIDE.

NOTE: WE RECOMMEND USING THREAD-LOCKER ON ALL SCREWS.