

# INSTRUCTION SHEET



## SEAT PAN KIT FOR 2015+ INDIAN SCOUTS & 2016+ SCOUT 60

### INCLUDED COMPONENTS:

- (1) Seat Pan
- (1) Front Seat Bracket
- (1) Rear Seat Bracket
- (1) Seat
- (1) Bushing
- (1) Hardware Kit

### NOTE:

These instructions work for installation of *both* the Klock Werks Klassic and Outrider seat pan kit.

### QUESTIONS?

-  **EMAIL:** info@getklocked.com
-  **CALL:** (605) 996.3700



1. Protect all painted surfaces
2. Remove stock seat by pulling up on the nose and sliding the back off of the mount post



6. Install button head bolt with spacer into threaded hole at the rear of the seat area  
**TORQUE TO:** 6-8 ft-lbs



3. Remove the rubber flap over the fuel tank mount by pulling at an angle



7. Install seat pan by sliding the rear of the pan over the spacer installed in step 5 and then secure with supplied bolts on top of the fuel tank bracket plate. **TORQUE TO:** 8-10 ft-lbs



4. Remove the barb fitting on the fuel tank bracket plate and the rear mount post assembly



8. Install front seat bracket onto the bottom of the seat in the kit using 2 of the supplied carriage bolts, washers and lock nuts finger tight



5. Remove the front two hex bolts on the fuel tank bracket plate



**NOTE:** If you have the Klassic seat kit, the hardware is already on the seat pan. The only thing to add would be two flat washers to the two rear mount bolts

## INSTRUCTION SHEET



9. Install the rear seat bracket to the motorcycle frame using supplied hex bolts and washers finger tight



10. Set seat onto the rear bracket and align the front bracket so it slides in between the tabs on the seat pan



11. Install bushing in the vacant space inside the front mount bracket and install supplied long hex bolt with washers and acorn nut to secure



12. Install flat washer, lock washer and nut to each of the rear seat mount studs.



13. Torque all remaining fasteners and enjoy your Klock Werks seat pan kit!
  - a. **Rear seat bracket bolts**  
Step 9: 8-10 ft-lbs
  - b. **Long hex bolt**  
Step 11: 6-8 ft-lbs
  - c. **All four seat nuts:**  
90-120 inch-lbs

**CAUTION:** Klock Werks cannot be held responsible for any damage to painted surfaces during removal or addition of Klock Werks parts.