

Copyright © 2017 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 30-114

MUD FLAP KIT

2/1/2017

FITMENT: VICTORY CC/CR/CCT/MAGNUM/HARDBALL 2010-NEWER

TOOLS NEEDED: PHILLIPS SCREWDRIVER

7MM WRENCH

4MM ALLEN WRENCH

10MM WRENCH

CLEANING RAG

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

ESTIMATED INSTALLATION TIME: 10 TO 15 MIN.

INSTALLATION:

1. USING A RAG CLEAN BOTH SIDES OF THE EXHAUST CROSS BRACE ON THE BACK OF THE BIKE AS SHOWN IN FIG. 1.
2. INSTALL THE M4 SCREWS THROUGH THE CAP RETAINERS AND THROUGH THE SIDE OF THE MUD FLAP WITH THE CHROME INSERT. SEE FIG. 2.
3. INSTALL A FLAT WASHER AND M4 LOCK NUT ON BOTH M4 SCREWS AND TIGHTEN WITH A SCREWDRIVER AND 7MM WRENCH. SEE FIG. 2.
4. SNAP THE SHOW CAPS ON BOTH SCREWS. SEE FIG. 2.
5. LOOSELY INSTALL THE MUD FLAP TO THE EXHAUST CROSS BRACE AS SHOWN IN FIG. 3. NOTE: THE MUD FLAP WILL BE ON THE REAR OF THE BRACE.
6. CENTER THE MUD FLAP ON THE BIKE AND WITH THE M6 SCREWS RESTING ON THE BOTTOM OF THE LARGE CUTOUTS TIGHTEN THE SCREWS.

