

Copyright © 2012 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 41-156**3PC LID NET SET-TRUNK
AND SADDLEBAG
CAN-AM SPYDER RT**

12/6/2012

TOOLS NEEDED: TORX T20 DRIVER

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

SECTION ONE – INSTALLING TRUNK LID NET

1. USING THE T20 TORX DRIVER REMOVE THE 4 SCREWS AS SHOWN IN FIG. 1
2. REINSTALL THE TORX SCREWS WITH THE PLASTIC MOUNTING CLIPS PROVIDED AS IF IT WERE A WASHER, LEAVING THE “S” HOOK HOLE POINTING IN TOWARD THE CENTER OF THE TRUNK LID. SEE FIG. 1
3. ATTACH ONE OF THE NETS FROM THE KIT TO THE MOUNTING CLIPS AS SHOWN IN FIG. 1

SECTION TWO-INSTALLING SADDLEBAG LID NETS

1. USING THE T20 TORX DRIVER REMOVE THE 4 SCREWS AS SHOWN IN FIG. 2
2. REINSTALL THE TORX SCREWS WITH THE PLASTIC MOUNTING CLIPS PROVIDED AS IF IT WERE A WASHER, LEAVING THE “S” HOOK HOLE POINTING IN TOWARD THE CENTER OF THE SADDLEBAG LID. SEE FIG. 2
3. ATTACH ONE OF THE NETS FROM THE KIT TO THE MOUNTING CLIPS AS SHOWN IN FIG. 2
4. REPEAT ON OTHER SADDLEBAG.

**FIG. 1****FIG. 2**

Scan code
with your
smartphone to
view video

