

Copyright © 2017 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 41-182

KEY COVER

5/8/2017

FITMENT: CAN-AM SPYDER, 2008-NEWER

TOOLS NEEDED: SUPER GLUE

PAPER TOWEL

**PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.****ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.****INSTALLATION:**

1. SEPARATE THE TWO HALVES OF THE KEY COVER AND LAY THEM ON A CLEAN PAPER TOWEL. SEE FIG. 1.
2. APPLY FOUR SMALL DROPS OF SUPER GLUE TO THE INSIDE OF THE FRONT HALF AS SHOWN IN FIG. 1. (**NOTE: THE FRONT IS THE THINNER HALF**)
3. SNAP THE FRONT AND BACK TOGETHER AS SHOWN IN FIG. 2.
4. INSTALL KEY RING.

4 DROPS OF  
SUPER GLUE**FIG. 1**FRONT  
(THIN)BACK  
(THICK)**FIG. 2****WARNING**

KEEP THE NUMBER OF KEYS AND FOBS TO A MINIMUM ON THIS KEY RING. EXCESSIVE WEIGHT MAY CAUSE DAMAGE TO IGNITION.

Copyright © 2017 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 41-182

KEY COVER

5/8/2017

FITMENT: CAN-AM SPYDER, 2008-NEWER

TOOLS NEEDED: SUPER GLUE

PAPER TOWEL

**PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.****ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.****INSTALLATION:**

1. SEPARATE THE TWO HALVES OF THE KEY COVER AND LAY THEM ON A CLEAN PAPER TOWEL. SEE FIG. 1.
2. APPLY FOUR SMALL DROPS OF SUPER GLUE TO THE INSIDE OF THE FRONT HALF AS SHOWN IN FIG. 1. (**NOTE: THE FRONT IS THE THINNER HALF**)
3. SNAP THE FRONT AND BACK TOGETHER AS SHOWN IN FIG. 2.
4. INSTALL KEY RING.

4 DROPS OF  
SUPER GLUE**FIG. 1**FRONT  
(THIN)BACK  
(THICK)**FIG. 2****WARNING**

KEEP THE NUMBER OF KEYS AND FOBS TO A MINIMUM ON THIS KEY RING. EXCESSIVE WEIGHT MAY CAUSE DAMAGE TO IGNITION.