

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

CALIPER COVERS

FITS HONDA

PART NO. 55-310

VTX 1300

Copyright© 2003 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

TOOLS NEEDED: 12MM WRENCH
5MM ALLEN WRENCH

INSTALLATION:

1. USING 12MM WRENCH, REMOVE THE TWO HEX HEAD BOLTS FROM THE FORKS THAT ARE HOLDING THE CALIPER ON.
2. INSTALL THE NEW CALIPER COVER USING THE TWO SPACERS PROVIDED ON THE INSIDE OF THE NEW COVER AND USING THE TWO ALLEN HEAD BOLTS PROVIDED.

NOTE: WE RECOMMEND USING LOCTITE ON BOLTS.