

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 63-303

SADDLEBAG STAYS
YAMAHA VSTAR 950 & 1300

03/24/09

TOOLS NEEDED: 5MM ALLEN WRENCH 6MM ALLEN WRENCH

NOTE:

- FOR THE VSTAR 950 USE 2 - 70MM LONG BUTTON SOCKET HEAD CAP SCREWS THAT ARE PROVIDED FOR MOUNTING THE REAR OF THE SADDLEBAG STAYS AND USE 2 - 80MM LONG BUTTON SOCKET HEAD CAP SCREWS THAT ARE PROVIDED FOR MOUNTING THE FRONT OF THE SADDLEBAG STAYS.
- FOR THE VSTAR 1300 USE 4 - 70MM LONG BUTTON HEAD CAP SCREWS THAT ARE PROVIDED TO MOUNT BOTH FRONT AND REAR OF THE SADDLEBAG STAYS.

1. USING A 6MM ALLEN WRENCH REMOVE THE FRONT LEFT SIDE SCREW FROM THE LEFT REAR FENDER STRUT COVER.
2. ALIGN THE FRONT LEFT SIDE SADDLEBAG STAY MOUNTING HOLE OVER THE EXISTING HOLE IN THE STRUT COVER MAKING SURE THAT THE SADDLEBAG STAY IS ANGLED OUT AND TOWARDS THE REAR OF THE BIKE. INSTALL ONE OF THE PROVIDED M8 SCREWS THROUGH THE SADDLEBAG STAY AND STRUT COVER INTO THE OEM HOLE AND HAND TIGHTEN.
3. USING A 6MM ALLEN WRENCH REMOVE THE REAR LEFT SIDE SCREW FROM THE LEFT REAR FENDER STRUT COVER. BE CAREFUL ONCE THE SECOND SCREW IS REMOVED, SO THAT THE COVER DOESN'T ROTATE AND SCRATCH THE FENDER.
4. ALIGN THE REAR LEFT SIDE SADDLEBAG STAY MOUNTING HOLE OVER THE EXISTING HOLE IN THE STRUT COVER. INSTALL ONE OF THE PROVIDED M8 SCREWS THROUGH THE SADDLEBAG STAY AND STRUT COVER INTO THE OEM HOLE AND HAND TIGHTEN.
5. WITH A 5MM ALLEN WRENCH TIGHTEN BOTH LEFT SIDE SADDLEBAG STAY SCREWS DOWN TIGHT.
6. REPEAT STEPS 1THROUGH 5 FOR THE RIGHT SIDE.