

# BIG BIKE PARTS®

## INSTALLATION INSTRUCTIONS

Copyright© 2005 by Big Bike Parts, Inc.® No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.®

PART # 81-103 / 81-104

RADIATOR GRILLE  
SUZUKI VZ1600, VN1500P '02 - '03  
VN1600B '04 - '05

TOOLS NEEDED: 4MM ALLEN WRENCH  
10MM WRENCH

### INSTALLATION:

1. PLACE RUBBER ISOLATION PADS PROVIDED ON THE BACK OF GRILLE TO KEEP FROM RATTLING AGAINST OEM MESH GRILLE.
2. USING 10MM WRENCH, REMOVE BOLTS HOLDING HORN ON, REMOVE WIRES FROM HORN AND SET HORN ASIDE.
3. USING 4MM ALLEN WRENCH, REMOVE THE FOUR BOLTS HOLDING OEM GRILLE COVER. THESE BOLTS WILL NOT BE REUSED.
4. STARTING WITH THE TOP SCREWS, PLACE THEM THROUGH THE RADIATOR GRILLE WITH A SPACER BEHIND THE GRILLE ON EACH SCREW. START THE TOP SCREWS AND THEN START THE BOTTOM SCREWS. MAKE SURE GRILLE IS CENTERED AND TIGHTEN DOWN ALL SCREWS.
5. REINSTALL THE HORN AS REMOVED IN STEP #2.